

Windscreen Repair Kit 433070

A self contained kit
for the repair of stone chips and bulls eye breaks to laminated windscreens.
All the tools and consumable items needed for an easy and professional repair.
Tools included in the kit require a separate 12 volt power source.
Leads and adaptors supplied



Items included in the kit

- Image Spider Jig
- 12v Mini-Drill
- 12v UV Lamp
- Vacuum/Pressure Pump
- Moisture Tube
- Connector Tube (injector)
- Injector
- Pit polish
- Crax Fill Poly Resin
- Pit Fill Poly Resin
- Inspection Mirror
- Probe
- O-Ring Small (10)
- O-Ring Large (10)
- Razor Blades
- Large Pit Adaptor
- Drill Bur
- Curing Film (booklet)
- Needle
- Syringe